


Chemical Process Utilities
Prof. Shishir Shina
Department of Chemical Engineering
Indian Institute of Technology, Roorkee

Lecture – 4
Fuel Analysis

Welcome to the fuel analysis concept of chemical process utilities. Before we go into the detail of the different aspects of fuel analysis, which we have partially discussed in the previous lecture, let us look at what we covered previously.

(Refer Slide Time: 00:45)




Previously, we have covered the various thermodynamic aspects of power generation and refrigeration in which we have discussed the various concept of different cycles vapor power cycles, Carnot cycle, Rankine cycle etc. In this particular lecture, we will cover the approximate and ultimate analysis. Apart from this, we will discuss the concept of heating value.

(Refer Slide Time: 01:10)

Introduction

- Several chemical processes require external heating for conducting a specific work.
- Variety of fuels are available to produce heat. Among them, the cheapest and easily available fuel needs to be used.
- Second, the selection of fuel depends upon the type of use. If contamination is the issue, then high quality fuel must be used.
- Each fuel has its own advantages and limitations. Among them, the most referring factor is the amount energy producing on burning a unit mass (kg) of fuel, called as its calorific value (J/kg).



Before we go into the detail, as you know, there are various chemical processes requiring external heating for conducting a specific work. Whenever there is a requirement for external heating, we have to look into several different parameters. The one parameter or one aspect is the fuel as we discussed in the previous lecture; there is a variety of fuels available as of date but based on our requirement based on other issues like environment calorific value, n number of choices available.


So, we can say the variety of fuels is available to produce heat that is the most generic term. Among them, the cheapest and easiest available fuel needs to be used. The reason is that whenever we are discussing any process or our ultimate aspect is to have a useful product from the raw material in that case if we are overlooking such kind of a concept like cheapest or easily available fuel.

In that case, our product cost will be on the higher side. So, we have to look into this particular aspect. Now the second aspect is the selection of fuel. This usually depends on the type of use. If contamination is the issue, high-quality fuel must be used. Like, see the cheap quality fuel having high contamination may be available at a very low cost, but ultimately whenever we go for the process which is attributed to the environmental issues calorific value efficiency of the system then definitely the cost plays a very vital role.

So, we have to optimize the thing. So, based on this thing, we need to choose the fuel. Now each fuel has its own advantage and limitation. Among them, the most referring factor is the amount of energy produced on burning a unit mass of fuel called the calorific


value, and it is measured in joules per kilogram. This is the foremost requirement as far as the engineering perspective is in question because, ultimately, we have to supply the heat to the target.

(Refer Slide Time: 03:52)




Introduction

- Other factors includes the amount of ash, pollutants, volatile matters, and moisture present in the fuel.
- To obtain these informations, usually two basic analysis needs to be carried out termed as;
 1. Proximate analysis
 2. Ultimate analysis



Other factors include the amount of ash pollutants because of environmental issues. When we talk about energy simultaneously, we cannot overlook the importance of the environment. So, pollutants, volatile matters, other impurities, moisture etc. All these things need to be addressed when we are going for the choice of fuel. Two basic analyses need to be carried out to obtain this information, basically, ash calorific value etc. One is the proximate analysis another one is the ultimate analysis.


(Refer Slide Time: 04:38)



Proximate Analysis


Proximate analysis of a fuel determines:

- the percentage of material in a gaseous form during burning (volatile matter)
- the percentage of material in a solid state (fixed carbon)
- The percentage of moisture content in a fuel
- the percentage of inorganic waste material (ash)
- They are determined by means gravimetric tests, both direct and indirect, that allow their calculation.



Now let us have a look at the proximate analysis. The proximate analysis of fuel determines how much percentage of material in the gas was formed during burning, reflecting the quantity of volatile matter. The percentage of material in solid-state i.e., fixed carbon, the percentage of moisture in fuel, the percentage of inorganic waste material, ash. They are determined by direct and indirect gravimetric tests that allow their calculation.

(Refer Slide Time: 05:18)



Proximate Analysis

- Higher volatile matter content can lead to increased gaseous product formation. These gaseous products usually have low calorific value.
- A quality fuel have higher number of fixed carbon content. This will lead to higher charcoal formation, used in industrial heating applications
-


Higher volatile matter content can lead to increased gaseous product formation, and these gaseous products usually have a very low calorific value. So, the quality of fuel must be addressed. Now usually, the quality fuel has a higher fixed carbon content. This sometimes leads to higher charcoal formation used in the industrial heating application. So, this thing has advantages or disadvantages both ways.

Now let us have a brief discussion about the proximate analysis. Now usually, when we go for the determination of moisture content, it reflects in terms of percentage. First, we must know how we can measure this. We require a crucible, and at the outset, you need to weigh the dry crucible

(Refer Slide Time: 06:22)

Procedure: Proximate Analysis

- Moisture content (%):
 1. Weigh the dried crucible
 2. Put 1 gram of solid fuel into the crucible and spread it uniformly
 3. Again weigh the crucible with sample to obtain the exact weight
 4. Heat the sample in a microwave oven for 1 hours at about 105-110 deg. C
 5. Carefully cool the sample in a desiccator to avoid atmospheric moisture contamination
 6. Weigh the crucible




So, when you have weighed the dry crucible, put one gram of solid fuel into the crucible, and you need to spread it uniformly so that the layers and other things or stagnant zone cannot form. Again weigh the crucible with the sample to obtain the exact weight. Heat the sample in a microwave oven for one hour about 105 to 110 degrees Celsius or any oven. Now carefully cool the sample in a desiccator to avoid any moisture contamination because the atmospheric moisture may again re-enter the sample, and whatever results you get may be erroneous. Weigh the crucible.

(Refer Slide Time: 07:12)

Procedure: Proximate Analysis

- Moisture content (%):

$$\text{Moisture content}(\%) = \frac{\text{loss in weight of sample}}{\text{Initial weight of fuel}} \times 100$$
- Volatile Matter (%):
 1. Place the same sample with a lid in a pre-heated muffle furnace at about 900 deg. C for 7 minutes
 2. Cool it in an open air for a minute and then place it in a desiccator.
 3. Weigh the crucible with lid for the mass loss



Through this mathematical equation you can find out that what is the moisture content that is

$$\text{Moisture content}(\%) = \frac{\text{loss in weight of sample}}{\text{Initial weight of fuel}} \times 100$$

So, by this way, you can calculate the moisture content.

Steps to determine the volatile matter:

Place the same sample with a lid in a preheated muffled furnace at around 900 degrees Celsius for 7 minutes.

Cool it in an open-air for a minute, place it in a desiccator, and weigh the crucible with lead to determine the mass loss.

(Refer Slide Time: 08:16)

The slide is titled "Procedure: Proximate Analysis". It contains the following information:

- Volatile Matter (%):
$$\text{Volatile matter (\%)} = \frac{\text{loss in weight of sample}}{\text{Initial weight of fuel}} \times 100$$
- Ash content (%):
 1. Same crucible should be placed in a muffle furnace without lid for half an hour. The temperature should be between 550-750 deg. C
 2. Allow it to cool in a open air for some time and then put it in a desiccator for cooling
 3. Weigh the crucible for weight loss in the sample

A small video inset on the right side of the slide shows a man in a suit speaking.

There is a mathematical relationship through which you can calculate the volatile matter

$$\text{Volatile matter (\%)} = \frac{\text{loss in weight of sample}}{\text{Initial weight of fuel}} \times 100$$

So, in this way, you can calculate the volatile matter.

Then coming to the ash content. It requires the same crucible, which should be placed in a muffled furnace without a lid for half an hour, and you have to maintain the temperature between 500 to 750 degrees Celsius.

You need to allow it to cool in the open air for some time and then put it in a desiccator for cooling. Perform the weighing operation for the crucible to determine the weight loss of the sample.


(Refer Slide Time: 09:10)

Procedure: Proximate Analysis

- Ash content (%):

$$\text{Ash content (\%)} = \frac{\text{loss in weight of sample}}{\text{Initial weight of fuel}} \times 100$$
- Fixed carbon (%):

$$\text{fixed carbon (\%)} = 100 - (\% \text{moisture} + \% \text{volatile matter} + \% \text{ash content})$$



Now ash content again you can calculate through this mathematical relationship that is

$$\text{Ash content (\%)} = \frac{\text{loss in weight of sample}}{\text{Initial weight of fuel}} \times 100$$

This will give you the ash content in percentage.

So, as far as we need to determine the fixed carbon percent, there is a simple mathematical relationship to assess the fixed carbon percentage in the sample.


$$\text{fixed carbon (\%)} = 100 - (\% \text{moisture} + \% \text{volatile matter} + \% \text{ash content})$$

So, by this way, you can find out how much percentage of fixed carbon is present in the sample in question.

(Refer Slide Time: 10:05)

Standards: Proximate Analysis


Constituents	Standard	Effecting parameters
Moisture	ASTM D3173-11	Storage durability, dry matter loss, heat loss, self ignition, plant design
Volatile matter	ASTM D3175-11	Thermal decomposition behavior
Ash	ASTM D3174-12	Dust emission, ash manipulation, ash disposal, combustion technology
Fixed carbon	ASTM D3172-07a	-



There are various standards as applicable by the ASTM American Society for Testing of Materials. They put forward certain procedures or certain methods and standards for the proximate analysis. As for moisture, the ASTM standard is D3173-11, where the affecting parameters are storage durability, dry matter loss, heat loss, self-ignition, plant design.

Similarly, for volatile matter, ASTM D3175-11, reflects the thermal decomposition behavior of the sample in question. For ash ASTM D3174-12, the effecting parameter are dust emission, ash manipulation, ash disposal, combustion technology etc. For the fixed carbon, the prevailing ASTM standard is D3172-07a.

(Refer Slide Time: 11:17)



The slide is titled "Ultimate Analysis" in blue text. It contains four bullet points: "Coal (or any biomass) is composed primarily of carbon along with other elements such as hydrogen, oxygen, nitrogen and sulfur.", "It is essential to determine these elements before using the fuel for its effective combustion as well as for the utility design.", "Ultimate analysis (or elemental analysis) helps to determine the net amount of oxygen required for the combustion of specific amount of fuel.", and "Determination of C, N and S helps to control the pollution associated from their oxides." In the bottom right corner of the slide, there is a small video inset showing a man in a suit and glasses speaking. At the bottom of the slide, there are logos for "unacademy" and "unacademy" and the number "13".

Now coming to the ultimate analysis, we usually know that coal or any other biomass (it is very applicable to biomass) is composed primarily of carbon and other elements like hydrogen, oxygen, nitrogen, sulfur. Now it is quite essential to determine these elements before using the fuel for its effective combustion and utility design.

Now why I am talking about this utility design or effective combustion because whenever we are using it as fuel, all these things may either hinder or may create a problem because sometimes sulfur is present then definitely it may corrode the system, or it may impart the hydrogen sulfide or any of gas which may create an environmental issue. Similarly, other nitrogen, oxygen, etc., like nitrogen, will not impart calorific value in the system.


So, before taking or designing our utility system, we should know the nature of the fuel. Now ultimate analysis sometimes carries the information relevant to the elemental

analysis, or sometimes it is referred to as elemental analysis. This helps to determine the net amount of oxygen required for the combustion of a specific amount of fuel.

Whenever we perform the combustion reaction, we definitely need to know how much oxygen is required. So, unless otherwise, we do not have any clue about the combustible material present in that particular sample, we do not have any information, or we do not have any knowledge about the oxygen requirement in this quiz. So, therefore this particular information is quite essential for assessing the exact requirement of oxygen.

So, the determination of carbon, nitrogen, and sulfur helps to control the pollution associated with their oxides, as this may pose a serious environmental problem. Now let us discuss the procedure through which we can carry out the ultimate analysis. So, first have a look at the carbon and hydrogen.

(Refer Slide Time: 14:04)



You must have a specific amount of sample, maybe 2 to 2.5 grams of the sample placed inside the combustion chamber, which is here in the figure. Now the weight of the sample is to be taken very precisely because, ultimately, it will give you proper information.

(Refer Slide Time: 14:23)

Procedure: Ultimate Analysis

- The combustion takes place in a closed tube where enough oxygen is supplied continuously.
- The carbon and hydrogen present in the sample will convert into CO_2 and H_2O .
- The oxygen gas will also work as a carrier for these gases to move outside the chamber.

Then the combustion takes place in this closed tube where enough oxygen is supplied continuously for the combustion purpose. So, here we are supplying the pure oxygen from here and the carbon and hydrogen present in the sample they invariably will convert into carbon dioxide and water or H_2O . The oxygen gas will also work as a carrier of these gases to move outside the chamber. So, you have the sample ports over here.

(Refer Slide Time: 15:04)

Procedure: Ultimate Analysis

- CuO pellets will catalyze the reaction and allows complete combustion of the carbon traces and the partially burnt CO gas.
- It will also help for the complete conversion of hydrogen to H_2O
- Anhydrous CaCl_2 and KOH solution absorbs the H_2O and CO_2 , respectively.

Now, CuO pellets will catalyze the reaction and allow the complete combustion of the carbon traces and partially burnt CO gas. So, it will help for the complete conversion of hydrogen to water. Now, anhydrous CaCl_2 and KOH solution absorbs the H_2O and CO_2 , respectively. So, in this way, you can assess because you have a pre-knowledge about these solutions. So, you can easily carry out how much carbon and hydrogen are present.

(Refer Slide Time: 15:55)

Procedure: Ultimate Analysis

- The change in mass of these absorbers are monitored separately. The difference gives the amount of H₂O and CO₂ produced during the combustion process.

$$C + O_2 \rightarrow CO_2; \quad H_2 + \frac{1}{2}O_2 \rightarrow H_2O$$

The change in mass of these absorbers is monitored separately. So, whatever difference occurred gives the amount of H₂O and CO₂ produced during the combustion process. So, you can take the cognitions of these two reactions, that is



(Refer Slide Time: 16:23)

Procedure: Ultimate Analysis

$$\% C = \frac{\text{increase in wgt of KOH tube} \times 12 \times 100}{\text{wgt of coal sample taken} \times 44}$$

$$\% H = \frac{\text{increase in wgt of CaCl}_2 \text{ tube} \times 2 \times 100}{\text{wgt of coal sample taken} \times 18}$$

You can find out how much percentage of carbon is present in the sample by this mathematical relationship that is

$$\% C = \frac{\text{increase in wgt of KOH tube} \times 12 \times 100}{\text{wgt of coal sample taken} \times 44}$$

12 and 44 are the molecular weight of C and CO₂, respectively. Similarly if we need to find out the percentage of hydrogen present in the sample

$$\% H = \frac{\text{increase in wgt of CaCl}_2 \text{ tube} \times 2 \times 100}{\text{wgt of coal sample taken} \times 18}$$


18 is the molecular weight of H₂O.

(Refer Slide Time: 17:20)

Procedure: Ultimate Analysis

Nitrogen determination by Kjeldahl's method:

- Many organic compounds when heated with conc. H₂SO₄ in presence of CuSO₄ & K₂SO₄, the nitrogen get converted into (NH₄)₂SO₄.
- The (NH₄)₂SO₄ obtained is then decomposed with caustic soda or caustic potash resulting in NH₃ evolution.
- NH₃ is then passed into H₂SO₄ of known quantity & strength.





Next is how we can determine the nitrogen percentage. So, the determination of nitrogen is being carried out by Kjeldahl's method. For many organic compounds, when heated with concentrated H₂SO₄ in the presence of CuSO₄ and K₂SO₄, the nitrogen gets converted into (NH₄)₂SO₄. Ammonium sulfate obtained is then decomposed with the cause caustic soda or caustic potash resulting in ammonia evolution. The ammonia is then passed into the H₂SO₄ of known quantity and strength.

(Refer Slide Time: 18:15)

Procedure: Ultimate Analysis

- The remaining unreacted H_2SO_4 is titrated against NaOH Solution of known strength.
- Hence % of N_2 is then calculated as:

$$\% N_2 = \frac{(1.4 \times \text{normality of acid} \times \text{volume of acid used with } NH_3)}{\text{weight of organic compound}}$$



So, the remaining unreacted H_2SO_4 is then titrated against the sodium hydroxide solution of known strength. So, in this way, you can calculate the percentage of nitrogen present in the sample.

Now this is a simple mathematical formula that is

$$\% N_2 = \frac{(1.4 \times \text{normality of acid} \times \text{volume of acid used with } NH_3)}{\text{weight of organic compound}}$$



This is Kjeldahl's setup, very common and frequently used in the determination of nitrogen content.

(Refer Slide Time: 18:59)

Procedure: Ultimate Analysis


Nitrogen determination by Duma's method:

- Nitrogenous compound when heated with cupric oxide in CO_2 atmosphere converts to free nitrogen.

$$C_xH_yN_z + \left(2x + \frac{y}{2}\right) CuO \rightarrow x CO_2 + \frac{y}{2} H_2O + \frac{z}{2} N_2 + \left(2x + \frac{y}{2}\right) Cu$$



Now another method for determining ultimate analysis under this nitrogen determination is the Duma's method. In Duma's method, the nitrogenous compound, when heated with


the cupric oxide in a carbon dioxide atmosphere, converts into free nitrogen, and the simplified formula is



(Refer Slide Time: 19:52)

Procedure: Ultimate Analysis

- Traces of oxide of nitrogen can be produced, which are reduced to the elemental nitrogen by passing over heated copper spiral.
- To begin, the nitro meter's tap is left open. To discharge the air in the combustion tube, CO₂ is fed through it.





This is the typical diagram of Duma's method. There is a cupric oxide gauge, and this cupric oxide and organic compound are placed over here under the edges of coarse cupric oxide, and the reduced copper gauge and continuous supply of CO₂ enters into this one, and this is typical anatomy of the furnace and this it is subjected to this mercury chamber where nitrogen is get collected with the help of displacement of KOH solution and by this way you can find out the volume of nitrogen.

Now traces of oxide of nitrogen it can also be produced, which are reduced to the elemental nitrogen by passing over the heated copper spiral-like here. To begin, the nitrometer strap is left open to discharge the air in the combustion tubes, and CO₂ is fed through it.

(Refer Slide Time: 20:57)

Procedure: Ultimate Analysis

- Traces of oxide of nitrogen can be produced, which are reduced to the elemental nitrogen by passing over heated copper spiral.
- To begin, the nitro meter's tap is left open. To discharge the air in the combustion tube, CO_2 is fed through it.






So, when potash solution fails to reach the top and is fully absorbed by rising gas bubbles, it indicates that only CO_2 is arriving and that all air has been evacuated from the combustion tube. After that, the nitrometer is filled with the potash solution by lowering the reservoir and closing the trap.

(Refer Slide Time: 21:28)

Procedure: Ultimate Analysis

- The furnace is heated, and the temperature is raised progressively.
- The N_2 catches the N_2 that has been released from the chemical.
- When the combustion is finished, a high stream of CO_2 is pumped through the device to remove any remaining nitrogen.






After this, we can heat the furnace, raising the temperature progressively. The nitrogen catches the nitrogen that has been released from the chemical. When the combustion is completed, a high stream of CO_2 is pumped through the device to remove any remaining nitrogen, called nitrogen flushing. So, you can flush it out so that any nitrogen can be collected and measured.

(Refer Slide Time: 21:59)

Procedure: Ultimate Analysis

- After adjusting the reservoir such that the solution in it and the graduated tube are the same, the volume of gas collected is recorded.
- The temperature and air pressure are also recorded.

$$\% N_2 = \frac{[28 \times \text{volume of } N_2 @ N.T.P \times 100]}{[22400 \times \text{weight of organic compound}]}$$



After adjusting the reservoir such that the solution in it and the graduated tube are the same, the volume of the gas collected recorded, and the temperature and air pressure are also being recorded because it carries valuable information and with respect to the mathematical formula.

Now the percentage of nitrogen easily we can calculate with the help of this mathematical relationship


$$\% N_2 = \frac{[28 \times \text{volume of } N_2 @ N.T.P \times 100]}{[22400 \times \text{weight of organic compound}]}$$

(Refer Slide Time: 22:51)

Procedure: Ultimate Analysis

Determination of Sulfur:

- A known quantity of coal is burnt in a bomb calorimeter
- The residue ash is treated with dilute HCl
- The extract is treated with barium chloride solution to precipitate the sulfate as barium sulfate
- The precipitate is filtered, double washed, dried, and weighed
- The percentage of sulfur is computed from the weight of $BaSO_4$



Now at the outset, let us discuss how we can determine the sulfur. Sulfur, among all, is an extremely non-eco-friendly element under the ultimate analysis. So, for this, we require a bomb calorimeter. So, the unknown quantity of coal is burnt in the bomb calorimeter.

Whatever residue remains in the bomb calorimeter is supposed to be treated with dilute HCL. The extract is treated with barium chloride solution to precipitate the sulfate as barium sulfate. Now whatever precipitate is generated in due course of time is filtered, double washed, dried, and weight and a percentage of sulfur are computed from the weight of barium sulfate.


(Refer Slide Time: 23:57)

Procedure: Ultimate Analysis

$$\% S = \frac{\text{wgt. of } BaSO_4 \text{ obtained} \times 32 \times 100}{233 \times \text{wgt of coal sample}}$$

Sulfides	Sulfates	
• Chalcopyrite $CuFeS_2$	Alumite $KAl_2(SO_4)_3(OH)_6$	Gypsum $CaSO_4 \cdot 2H_2O$
• Galena PbS	Antlyorite $CaSO_4$	Hexahydrate $MgSO_4 \cdot 6H_2O$
• Greigite $Fe^2+Fe^{3+}_2S_4$	• Barite $BaSO_4$	Jarosite $(Na,K)Fe_3(SO_4)_2(OH)_6$
• Marcasite FeS_2	Bassanite $CaSO_4 \cdot 1/2H_2O$	Melanterite $FeSO_4 \cdot 7H_2O$
• Milarite NaS	Borohite $Na_2Mg(SO_4)_2$	Natrojarosite $NaFe_2(SO_4)_2(OH)_2$
• Pyrite FeS_2	Celsite $SiSO_4$	Roseite $FeSO_4 \cdot 4H_2O$
• Pyrrhotite $Fe_{1-x}S$	Coqumite $Fe_3(SO_4)_2 \cdot 9H_2O$	Szomolnokite $FeSO_4 \cdot H_2O$
• Sphalerite $(Zn, Fe)_2S$	Glauberite $Na_2Ca(SO_4)_2$	Thenardite Na_2SO_4
• Blende SbS		Tschermigite $NaN_3(SO_4)_2 \cdot 12H_2O$

▶ Major ▶ Minor ▶ Rare



This is the standard formula through which we can calculate the percentage of that is

$$\% S = \frac{\text{wgt. of } BaSO_4 \text{ obtained} \times 32 \times 100}{233 \times \text{wgt of coal sample}}$$


Some of the sulfides, sulfates etc., are present in the fuel, and some of them are present in the major quantity, and some of them are present in the minor quantity, and some of them are very rare. If you see the major component of pyrites, they are present in most of the fuel. Similarly, barite they are present in the minor quantity yes other they are in the rear one.

(Refer Slide Time: 24:45)

Procedure: Ultimate Analysis

Determination of Ash and Oxygen:

- The ash determination procedure is previously discussed in proximate analysis section.

$$\% \text{Oxygen} = 100 - (\%H + \%S + \%N + \%Ash)$$



Now under this head, that is a determination of ash and oxygen. So, we have already discussed the ash determination procedure in the proximate analysis. So, we can calculate the percentage of oxygen

$$\% \text{Oxygen} = 100 - (\%H + \%S + \%N + \%Ash)$$

(Refer Slide Time: 25:25)

Procedure: Ultimate Analysis


Material	C	H	O	N	S
Peat	55-60	6-6.5	30-35	1.5-2	0.6-1
Lignite	70-73	4.6-5.5	22-26	0.6-1.0	0.6-1.5
Bituminous	80	6	15	-	-
Anthracite	93	4	3	-	-



You can see here the percentage of carbon, hydrogen, oxygen, nitrogen, and sulfur in different types of coal samples. This is for reference, and like peat, it has a carbon content of 55 to 60% hydrogen, 6 to 6.5% oxygen, 30 to 35% nitrogen 1.5 to 2, and sulfur 0.621. Similarly, lignite has 70 to 73%. So, the more carbon, the better will be the calorific value.


Similarly, anthracite and bituminous coal they are having the highest percentage of carbon, like anthracite at 93% and 4% hydrogen, and approximately 3% oxygen. So, it is the purest form you can say of coal. Similarly, bituminous 80% carbon content hydrogen 6% and 15% oxygen. So, this is the thing, and that is why you find that bituminous and anthracite coal has a higher cost than peat lignite.

(Refer Slide Time: 26:29)



Total Carbon and Fixed Carbon

- Some of the carbon present in volatile matter is not included in fixed carbon
- Hence,
$$\text{Total carbon} = \text{fixed carbon} + \text{carbon in volatile matter}$$
- Higher the total carbon content, higher the fuel calorific value
- Higher the hydrogen content, higher the calorific value in gaseous products.



Now let us briefly discuss the total carbon and the fixed carbon. Some of the carbon present in the volatile matter is not included in the fixed carbon. So, therefore we need to find out

$$\text{Total carbon} = \text{fixed carbon} + \text{carbon in volatile matter}$$


The higher the total carbon content, the calorific fuel value, and the higher the hydrogen content, the higher the calorific value in the gaseous products. So, is by this way we can find out the total carbon.

(Refer Slide Time: 27:02)

Calorific Value

- Calorific value is determined using bomb calorimeter using Dulong formulae

Gross calorific value (G.C.V)

$$G.C.V = \frac{1}{100} \left[8080C + 34500 \frac{H - (O + N - 1)}{8} + 2220S \right] \text{ kcal/kg}$$


And let us have a brief discussion about the calorific value; this is determined using the bomb calorimeter, which we have already discussed using the Dulong formula equation. So, the gross calorific value that is sometimes referred to as GCV that is

$$G.C.V = \frac{1}{100} \left[8080C + 34500 \frac{H - (O + N - 1)}{8} + 2220S \right] \text{ kcal/kg}$$

In this chapter, we have discussed the ultimate analysis and proximate analysis. We have already discussed the importance of these two analyses because our ultimate aim is to produce or have fuel for the heating purpose, whatever we are using for the heating purpose. It should give a high calorific value. Apart from this, it should not impart any kind of environmental threats to the environment.

It should not impart any kind of pollutant aspect to any system it should not be a danger to the system in use like sulfur it may corrode like other components. So, we can design our system based on the better choice of fuel cost it should be cost-efficient. So, the ultimate cost of the product should not go on the higher side. Although availability also is very important, we will discuss the availability issue in due course of time in a separate lecture.

(Refer Slide Time: 28:59)

References

- Gavin Towler and Ray Sinnott, Utilities and Energy Efficient Design (2013), DOI: [10.1016/B978-0-08-096659-5.00003-1](https://doi.org/10.1016/B978-0-08-096659-5.00003-1)



If you like to have some more study or references, I have enlisted one of the references for you, you can have a look at these references for the future course of study, thank you very much.